



## Duraflex Diving Board & Stand Maintenance

Hose off the entire stand with fresh water each day of use. For indoor pools, the warm humid air off the pool surface condenses on cooler metal surfaces. This humid air contains traces of highly corrosive chlorination byproducts. Hose off the stand with fresh water every day, especially if the equipment was not used. To clean and protect the stainless steel in your facility try our **CitriSurf** and **Rust Rescue** maintenance products.

- ✓ Keep the fulcrum components clean, especially the tracks.
- ✓ Keep the roller clamp lock nuts, and anti-rattle lock nuts, snug and adjusted for a "no-rattle" clearance.
- ✓ The two grease fittings of the roller block should be lubricated every 2 weeks. Use "Mystic JT-6" grease and grease gun.
- ✓ The hinges that hold the board to the stand need 2 drops of oil every 2 weeks. Use lightweight oil as for door hinges.
- ✓ Tighten all unpainted bolts at the start of each season.
- ✓ Tighten rail clamp bolts monthly. Maintain steps with the same procedure as the diving board.
- ✓ The rubber channels on the underside of the board must be inspected monthly for signs of wear. They must be replaced if worn before any of the metal ribs contact the fulcrum.

### Wearable part to be checked:

516 Anti Rattle Clamp (x2)    518 Slide Bearing (x2)    521 Roller Clamp (x2)  
C208 Track (x2)    517 - Complete Roller Block Assembly  
MP112 - 30" Rubber Channel Set

